



installation

For land line connection:

1. Connect socket nr-1 to the SPKR socket on the computer.
2. Connect socket nr-2 to the MIC socket on the computer.
3. Optional - Connect socket nr-3 to the RESET of the computer *.

For cellular connection:

4. Connect socket nr-4 to the MIC socket on the cellular.
5. Connect socket nr-5 to the EARPHONE of the cellular.
6. Connect socket nr6 to the RING SENSOR and put it anywhere on the cellular , and attach it with a tape so it will not skid from the phone.

For both connections:

7. Connect the power supply to nr-7 socket.
8. Connect USB plug to the computer. (any empty socket)
9. Connect the LAND LINE plug to the LAND LINE socket on the wall.

you will need to make sure that the internet connection is established automatically upon restarting your computer. (in order to reconnect in case of restarting the computer buy remote control)

10. Make a new skype account on your computer.
11. On skype , go to “tools”, then “options”, then “calls”, then “show advance options” then check the box “automatic answer incoming calls”
12. On skype make auto logon.

13. Put the volume control on your computer to middle range.
14. Close all window on the desktop, except of the skype window .
15. You can close your screen if you wish to do so.

Operation

1. “On the go” you will need another computer with internet connection , skype installed, or a cellular phone with skype installed.
2. Add the user name you installed “on the bas station” to the computer or phone you are using now.

Incoming calls.

1. When receiving incoming call from the user name that is the “base station” make accept, then press the “#” key .
you can speak now.
2. To close the line press “*” twice, then disconnect the skype.

Outgoing calls

1. make a skype call to the “base station “ .
after a second or so the “base station will answer automatically.
2. press the “#” and you will get your “dial tone” where the adapter is installed..
3. open the dial pad on the skype and dial your nr as if you are in the “ base station” (no prefix at all!!!)
4. to close the line press “*” twice and then disconnect the skype call.

Troubleshooting

if you cannot see your “base station” user name on your local computer or phone it means that or the power went down in the base station (if no ups installed) , or the internet connection was lost , or the computer “fell”.

in order to reset your internet connection or to reset your computer you will need to use the following steps:

reset the computer by remote control

1. call your land line nr in the “base station”.
2. after 10 rings the line will open.
3. press “*” and then “3” . wait 6 sec and you will hear 3 beeps. the computer will make a “hard reset” .
4. close the line and wait about 3 min. you should get back your connection with the “base station” now.

* you need a pc technician to make a “reset” connection to the pc. (it is connected in parallel to the reset button of the computer)